



- Loosen the nuts in each end of the cylinder.
- Mount the restrictor as in drawing.
- Tighten the nuts in each end.
- The bottom nut should not be tightened very hard. It must give room for movement in the open hole.
- The restrictor prevents forward tilt.